

Post Mount Tower Installation Instructions

NWI POST MTG INST REV. 0 - 12/04

1. Use *BASE PLATE* as a template to mark and drill holes for use of fasteners which meet your local building codes.
2. Anchor the *POST MOUNT TOWER* to the concrete or deck surface using fasteners that meet local building codes. When mounting to a deck, you must thru bolt to the surface. *POST MOUNT TOWER* must be attached to the deck frame in some manner such as an angle bracket (not supplied). If angle bracket is not used, double up 2 x 6 blocking between joist and thru bolt mount using (4) mounting holes.

Note: Use the CONCRETE MOUNTING HOLE only on concrete surfaces and the (4) Outer mounting holes when mounting to asphalt, wood or other surfaces.

When surface mounting to composite or vinyl decking, it is recommended to notch decking around BASE PLATE.

3. If Concrete surface is slightly unlevel, place the *LEVELING PLATE* on the surface as shown. Use the (4) *LEVELING SCREWS* to level *POST MOUNT TOWER*. Once level, anchor to the concrete.
4. Once the *POST MOUNT TOWER* is secured to the surface, slide the post over it. Then using a long bar, tap the *LOCKING WEDGE* down into *POST MOUNT TOWER* to lock the post into position.
5. Installation is complete.

