

HEAVY DUTY GRAVITY LATCH

NW38338-R/NW38338-R-26/NW38338-R-ZPSCAN FOR MORE
INFORMATION

INSTRUCTIONS

NOTE: Prior to installing the latch, the gate should be mounted and the hinges should be adjusted to the proper position.

1. Position the edge of the latch to line up evenly with the edge of the gate. Mark the four screw hole positions.
2. Drill four pilot holes through the gate using a 1/8" drill bit.
3. Attach the latch to the gate using the 4 included #10 X 1.5" Pan Head Phillips screws.
4. With the latch in the locked position, place the catch over the bolt and mark the four mounting hole locations.
5. Drill four pilot holes 1.5" deep.
 - Use a 1/8" drill bit for soft materials.
 - Use a 9/64" drill bit for hard materials.
6. Attach the catch to the post using the 4 included #10 X 1.5" Pan Head Phillips screws.
7. Test latch operation to ensure proper alignment and function.

