

## NYLON GATE HANDLE

NW314S-BK



SCAN FOR MORE  
INFORMATION

### INSTRUCTIONS

1. Install vertically on the gate pull side at about head height (approx. 36" - 42") or where it feels most comfortable (Fig. 1 & 2).
2. Hold the handle in place and mark the two screw hole locations (Fig. 2 & 3).
3. To prevent splitting, pre-drill shallow pilot holes using a 3/32" bit (optional, but recommended).
4. Drive the provided mounting hardware through the handle flanges into the gate and tighten.
5. Test gate operation.

