

CONTEMPORARY GATE LATCH

NW38310Q



SCAN FOR MORE
INFORMATION

INSTRUCTIONS

1. Hold the latch against the post at your desired latch height and ensure it is level (Fig. 1).
2. Mark the four mounting holes and pre-drill holes using a 7/32" drill bit (optional but recommended).
3. Fasten the latch to the post using the (4) 5/16" x 1-3/4" lag screws.
4. Align the striker bar on the gate frame so it fits securely into the latch when closed. Mark hole locations, pre-drill, and attach with the (2) 1/4" x 1-1/4" lag screws (Fig. 2).
5. On the opposite side of the gate, align the handle with the latch shaft (Fig. 2).
6. Insert the 1/4"-20 x 1-1/4" screw through the handle and gate, and secure with the washer and nut on the inside.
7. Test gate operation to ensure smooth latch engagement and alignment and adjust if needed.

