

NYLON GATE BUMPER

NW6186-SD-BK



SCAN FOR MORE
INFORMATION

INSTRUCTIONS

1. Close the gate fully to identify contact point (Fig. 1).
2. Mark the bumper location where the gate contacts the post or frame (Fig. 1 & 2).
3. Pre-drill pilot holes (optional, but recommended for hardwood or metal).
4. Align the bumper and fasten it securely with the provided screws (Fig. 2).
5. Test gate operation by swinging it closed to confirm the bumper absorbs the impact and maintains proper latch alignment.

