

GRAVITY LATCH WITH FLOATING BAR

NW38203Q

SCAN FOR MORE
INFORMATION

INSTRUCTIONS

1. Position the latch body on the gate so that the floating bar aligns with the strike point on the post (Fig. 1 & 2).
2. Mark screw holes for both latch and strike components.
3. Pre-drill holes if needed to avoid wood splitting.
4. Attach the latch and striker using included fasteners.
5. Test gate operation and adjust as needed.

